



CLOUTH PORTABLE -DOCTOR-CHANGE®

Portable device for doctor blade changes while the machine is running

- High efficiency by optimising machine runtime
- Higher product quality thanks to cleaner cylinders
- Easy and secure handling
- Significantly improved safety
- · Less manual intervention in the process

FILM OF USAGE

This is how simple it is to make a lying change! The video shows the operating principle:



www.clouth.com

BLADE CHANGE ON THE RUN

Doctor blade changes while the machine is running



JOH. CLOUTH'

CLOUTH PORTABLE-DOCTOR-CHANGE®

Easy change and quick cleaning

Due to a sophisticated design and construction, the doctor blade can be changed or removed and re-installed while the machine ist running.

Highly efficient

Mounted on a transport cart, the CLOUTH PORTABLE-DOCTOR-CHANGE[®] can be aligned directly with the protruding doctor blade at the height and angle adjustment of the holder.

For application areas that are difficult to access, the CLOUTH PORTABLE-DOCTOR-CHANGE® can be easily attached to a bracket* individually adapted to the machine through its guide pins.

Comfortable to use

The 4-metre supply line of the pneumatic, intuitive two-hand operation ensures a safe distance to the working area. It can also be secured against unintentional restarting by means of the emergency stop button.

Easy operation

Practical transport trolley with device-tray and safety accessories. This ensures that all materials are easily to hand and ready for use at any time.

The control box with pressure indicator has an integrated maintenance unit. The CLOUTH DOCTOR-CLEAN[®] CPDC from our range of accessories can be used to quickly and reliably clean the guide rail along its entire length.

Design and Accessories

- All the components are made of high-quality, temperature-resistant stainless steel or aluminium.
- Robust transport trolley with storage tray and appropriate safety accessories*
- * Depending on its configuration, the CLOUTH PORTABLE-DOCTOR-CHANGE[®] may vary in equipment and technical details. Please note the scope of delivery and product description. Accessories only included if listed in the scope of delivery.



Joh. Clouth GmbH & Co. KG Johann-Clouth-Straße 1 – 5 D - 42499 Hückeswagen

Phone **+49 2192 853 - 0** Fax +49 2192 853 - 333

sales@clouth.com www.clouth.com

"We had great pleasure in further developing the existing product – especially with regard to standardisation."

Sabrina Östreich and Ivo Müller Research & Development Joh. Clouth GmbH & Co. KG

